

IMPORTANT PRODUCT INFORMATION

[Triangle with !] SAFETY INFORMATION

Use Responsibly. Read all instructions and safety information before use.

FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

Working with electricity can be dangerous unless proper safety precautions are taken. If you are not comfortable or are inexperienced with the processes and tools described in this manual, we recommend that you hire a licensed electrician. Installation by a qualified electrician may be required in your area. Refer to your local laws and building codes before performing electrical work; permits plus professional installation may be required by law.

WARNING: Electrical shock hazard

Disconnect power to installation area at your circuit breaker or fuse box before beginning installation. Always use caution when handling electrical wiring. Additionally:

- Turn off power at the fuse box before installing.
- Verify that the supply voltage is correct. Connect fixture to a 100VAC-240VAC 50/60Hz power source.
- Only install the Blink Wired Floodlight Camera on a 4" round, UL listed weatherproof electrical box.
- The ground wire must be connected to the light fixture. DO NOT INSTALL if a working earth ground connection is not available.
- Do not connect this light fixture to a dimmer switch or timer.
- Only use the provided screws and accessories to install your Blink Wired Floodlight Camera.
- Do not install on circuits feeding motor loads such as kitchen appliances, HVAC equipment, washer/ dryer or garage door openers.
- Do not install when it is raining.
- Do not install while others are standing below the electrical outlet box.
- SUITABLE FOR WET LOCATIONS.
- WALL MOUNT OR COVERED CEILING MOUNT ONLY.
- Wall mount direction: lamp head on top.
- SUITABLE FOR OPERATION IN AMBIENT NOT EXCEEDING 50°C.
- MINIMUM 90°C SUPPLY CONDUCTORS.
- Your device does not contain serviceable parts. Do not disassemble.

If you are in any doubt with the installation instructions, consult a qualified electrician.

To avoid risk of electric shock, do not touch your device or any wires connected to your device during a lightning storm.

CAUTION: Risk of fire

Do not install near combustible or flammable surfaces.

CAUTION: To reduce the risk of falling, take extra caution when using a ladder or similar equipment to mount the product.

For setup, mounting, and hardwire installation instructions, follow the included instructions or go to blink.com/setup.

Maintaining Your Blink Wired Floodlight Camera

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Don't expose your device to steam, extreme heat or cold. For example, do not install your device near any heat sources such as space heaters, heater vents, radiators, stoves, or other things that produce heat. Use your device in a location where temperatures remain within the device's operating temperature range set forth in this guide. Your device may get warm during normal use. To reduce the effect of the warming, place your device on a heat resistant surface.

Your device can withstand outdoor use and contact with water under certain conditions. However, your device is not intended for underwater use and may experience temporary effects from exposure to water. Do not intentionally immerse your device in water. Do not spill any food, oil, lotion, or other abrasive substances on your device. Do not expose your device to pressurized water, high velocity water, or extremely humid conditions (such as a steam room). To protect against electric shock, do not place cord, plug, or device in water or other liquids.

Following periods of extended use, the Blink Wired Floodlight Camera may feel hot to touch. Please wait 15 minutes after the Blink Wired Floodlight Camera is no longer in use before touching or moving it.

Do not stare directly at the LEDs for more than a few seconds to avoid eye injury.

Use only Blink branded accessories compatible with this product.

PRODUCT SPECIFICATIONS

Device Name: Blink Wired Floodlight Camera

Model Number: BFM00100UW

Electrical Rating: 100-240VAC, 50/60Hz, 45W

Operating Temperature: -4°F to 122°F (-20°C to 50°C)

Supplier's Declaration of Conformity – Compliance Information Statement

Device Name: Blink Wired Floodlight Camera

Model Number: BFM00100UW

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party and Party issuing Supplier's Declaration of Conformity:

[Amazon.com](https://www.amazon.com) Services LLC, 410 Terry Avenue North, Seattle, WA 98109, U.S.A.

blink.com/pages/certifications

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Pursuant to Section 15.21 of the FCC rules, changes or modifications to a Product by the user that are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device meets the FCC Radio Frequency Emission Guidelines. Information on the product is on file with the FCC and can be found by inputting such Product's FCC ID (which can be found on the device) into the FCC ID Search form available at fcc.gov/oet/ea/fccid.

This device complies with radio frequency radiation exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other product antenna or transmitter.

Innovation, Science and Economic Development Canada (ISED) Compliance

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Information Regarding Exposure to Radio Frequency Energy

This equipment complies with IC RSS-102 RF exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

RECYCLING YOUR DEVICE PROPERLY

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of, or recycle, your device in accordance with your local laws and regulations. For information about recycling your device, go to www.amazon.com/devicesupport.

BLINK TERMS & POLICIES

Terms of Service and Warranty

By purchasing or using the product, you agree to the Terms of Service found at <https://blink.com/blink-terms-warranties-and-notice>. For information on our warranty and any other applicable policy, visit <https://blink.com/blink-terms-warranties-and-notice>.

Amazon.com Services LLC, 410 Terry Avenue North, Seattle, WA 98109, U.S.A.

©2022 Amazon.com, Inc. or its affiliates. Amazon, Blink, and all related marks are trademarks of Amazon.com, Inc. or its affiliates.